


RONIN

Intelligent Battery Power Distributor

Quick Start Guide

V1.2 2016.02



Disclaimer

Thank you for purchasing the Ronin Intelligent Battery Power Distributor. Read this disclaimer carefully before using this product. By using this product, you hereby agree to this disclaimer and signify that you have read it fully. Please use this product in strict accordance with the manual and be sure to pay attention to the warnings. SZ DJI Technology Co., Ltd. and its affiliated companies assume no liability for damage(s) or injuries incurred directly or indirectly from improper use of this product. Refer to the User Manual for applicable information not herein contained.

This device complies with Part 15 of the FCC Rules.


DJI is the registered trademark of SZ DJI Technology Co., Ltd. (abbreviated as "DJI"). Names of product, brand, etc., appearing in this manual are trademarks or registered trademarks of their respective owner companies. This product and manual are copyrighted by DJI with all rights reserved. No part of this product or manual shall be reproduced in any form without the prior written consent or authorization of DJI.

This disclaimer is produced in various languages. In the event of divergence among different versions, the Chinese version shall prevail when the product in question is purchased in Mainland China, and English version shall prevail when the product in question is purchased in any other region.

Product Profile


The Ronin Intelligent Battery Power Distributor (the "power distributor") provides two P-TAP outlets for external filming equipment such as RED cameras.

Overview




Installation

1. Before attaching the Intelligent Battery to the power distributor, select the desired sound option for the buzzer which is triggered when the battery level drops below 10%.




2. Loosen the thumb screws on both sides of the Intelligent Battery and then slide the battery into the power distributor's battery slot. Ensure the connectors make good contact.






- Ensure the Intelligent Battery is turned off during installation.
 - Ensure the Intelligent Battery is firmly installed and the connectors make good contact. Failure to do so may lead to poor power and signal transmission.
-

3. Tighten the thumb screws on the Intelligent Battery to secure.




4. If you are installing onto the Ronin, use a hex key to remove the four screws on both sides of the Ronin battery buckle. Then mount the new battery buckle onto the Ronin and tighten the screws.




- Skip this step if using the Ronin-M.
-


5. Loosen the thumb screws on both sides of the power distributor. Slide the power distributor into the battery slot of the Ronin or Ronin-M. Ensure the connectors make good contact.



6. Tighten the thumb screws on the power distributor to secure.




7. Connect your filming equipment to the P-TAP outlets.



Mounting Holes

The power distributor can also be mounted on other equipment using the two standard 7 mm mounting holes.



Specifications

| | |
|----------------------|---|
| Weight | 125 g |
| Output Voltage | 12 V |
| Output Current | ≤8 A |
| Compatible Batteries | 844297-4350mAh-15.2V 824380-3400mAh-14.8V 423496-1580mAh-14.4V* |

- * If using the 423496-1580mAh-14.4V Intelligent Battery, a motor stall may cause your external equipment to unexpectedly shut down from the sudden voltage drop.

This content is subject to change.

Download the latest version from
www.dji.com/product/ronin-m

If you have any questions about this document, please contact DJI by sending a message to DocSupport@dji.com.