


# OSMO

## Mobile Device Holder

Quick Start Guide V1.0



## **Disclaimer and Warning**

Congratulations on purchasing your new DJI product. The information in this document affects your safety and your legal rights and responsibilities. Read this entire document carefully to ensure proper configuration before use. Failure to read and follow instructions and warnings in this document may result in serious injury to yourself or others, damage to your DJI product, or damage to other objects in the vicinity. This document and all other collateral documents are subject to change at the sole discretion of DJI. For up-to-date product information, visit <http://www.dji.com> and click on the product page for this product.

By using this product, you hereby signify that you have read this disclaimer and warning carefully and that you understand and agree to abide by the terms and conditions herein. You agree that you are solely responsible for your own conduct while using this product, and for any consequences thereof. You agree to use this product only for purposes that are proper and in accordance with all applicable laws, rules, and regulations, and all terms, precautions, practices, policies and guidelines DJI has made and may make available.

DJI accepts no liability for damage, injury or any legal responsibility incurred directly or indirectly from the use of this product. The user shall observe safe and lawful practices including, but not limited to, those set forth in this document.

## **Introduction**

The Mobile Device Holder for the Osmo secures your smartphone alongside the handle. Your smartphone can then serve as a real-time viewfinder with touchscreen camera control through the DJI GO app.

## **Specifications**


**Dimensions:** 116 mm × 30 mm × 34 mm

**Weight:** 118 g


**Max Clamping Dimensions:** 160 mm × 77 mm

## Installation


1. Attach the Mobile Device Holder to the rosette mount on the Osmo handle. Tighten the knob to secure.




2. Unfold the arms and adjust the pads.



3. Place one end of your mobile device into the arms. Push the other end, extending the arms until your entire mobile device is seated in the Mobile Device Holder.



4. Release your mobile device. Ensure it is secure. Adjust the pads if necessary.



5. Rotate your mobile device to the desired position.



## **WARNING**

1. Ensure the Mobile Device Holder and your mobile device are mounted securely to prevent damage to your property.
2. **DO NOT** force an oversized mobile device into the Mobile Device Holder.

The content is subject to change.

Download the latest version from  
[www.dji.com/product/osmo](http://www.dji.com/product/osmo)

If you have any questions about this document, please contact DJI by sending a message to [DocSupport@dji.com](mailto:DocSupport@dji.com).