



Osmo Action 6 光圈模式

配件使用情况	拍摄模式	支持光圈模式
无配件	拍照	自动/固定 F2.8/星芒 F4
	普通视频模式	
	人像模式	
	人物跟随	
	慢动作	
	运动延时	
	静止延时	固定 F2.8/星芒 F4
	超级夜景	大光圈 F2/ 固定 F2.8/星芒 F4
安装微距镜时	拍照	大光圈 F2/ 星芒 F4
	普通视频模式	
	人像模式	
	超级夜景	
	静止延时	
	运动延时	
安装增广镜时	拍照	自动/固定 F2.8/星芒 F4
	普通视频模式	
	人像模式	
	人物跟随	
	运动延时	
	超级夜景	大光圈 F2/固定 F2.8/星芒 F4
	静止延时	固定 F2.8/星芒 F4

注意：光圈模式显示以实际相机界面为准，支持的光圈模式可能会随固件版本更新而调整。



Osmo Action 6 Aperture Mode

Accessory Usage	Shooting Mode	Supported Aperture Modes
No Accessory	Photo	Auto/Fixed (f/2.8)/Starburst (f/4.0)
	Video	
	Portrait Mode	
	Subject Tracking	
	Slow Motion	
	Hyperlapse	
	Timelapse	Fixed (f/2.8)/Starburst (f/4.0)
	SuperNight	Large Aperture (f/2.0)/Fixed (f/2.8)/Starburst (f/4.0)
With Macro Lens Attached	Photo	Large Aperture (f/2.0)/Starburst (f/4.0)
	Video	
	Portrait Mode	
	SuperNight	
	Timelapse	
	Hyperlapse	
With FOV Boost Lens Attached	Photo	Auto/Fixed (f/2.8)/Starburst (f/4.0)
	Video	
	Portrait Mode	
	Subject Tracking	
	Hyperlapse	
	SuperNight	Large Aperture (f/2.0)/Fixed (f/2.8)/Starburst (f/4.0)
	Timelapse	Fixed (f/2.8)/Starburst (f/4.0)

Note: The aperture modes displayed in the camera interface take precedence. These modes may be updated in future firmware releases.