

## DJI Mic 3 OsmoAudio Compatibility List

Transmitter (TX) Functions	Osmo Action 4	Osmo Action 5 Pro	Osmo Pocket 3	Osmo 360
LED Indicator	√	√	√	√
Vibration	√	√	√	√
Record While Filming	√	√	√	√
Low Cut	√	√	√	√
32-Bit Float Recording	√	√	√	√
Transmitter Auto Off	√	√	√	√
Clipping Control	√	√	√	×
Format	√	√	√	√
Version	√	√	√	√
Audio Channel	×	√	√	√
Channel Assignment (TX1/TX2)	×	√	√	√
Transmitter Gain	√	√	√	√
Mute	√	√	√	√
Noise Cancellation	√	√	√	√
Voice Tone	√*	√*	√*	√
Adaptive Gain Control	×	×	×	√
File Option	√*	√*	√*	√
Startup Auto Recording	√*	√*	√*	√
Loop Recording	√*	√*	√*	√
Low Power Auto Recording	×	×	×	√
REC Stop	×	×	×	√
Noise Cancellation via Button	×	×	×	√

- Features marked with an asterisk (\*) require DJI Mimo App setup to enable.