

DJI Osmo Action 3 Release Notes

Date: 2024.09.20

Firmware Version: 01.04.01.10

DJI Mimo App iOS: v2.1.0

DJI Mimo App Android: v2.1.0

What's New

- Added support for using with Osmo Action Extreme Battery Plus (1950 mAh).

Notes:

Custom Mode settings will be reset after the firmware update.

If the update fails, follow the steps for troubleshooting.

1. Restart Osmo Action 3 and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect Osmo Action 3 to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.

DJI Osmo Action 3 Release Notes

Date:	2023.04.26
Firmware Version:	v01.03.10.30
DJI Mimo App iOS:	v1.8.16
DJI Mimo App Android:	v1.8.16

What's New

- Added Enhanced Image Quality in video shooting mode for certain resolutions and frame rates.
- Improved image quality when used as a webcam or when livestreaming.
- Optimized UI display for certain functions.
- Fixed some minor bugs.

Notes:

Custom Mode settings will be reset after the firmware update.

If the update fails, follow the steps for troubleshooting.

1. Restart Osmo Action 3 and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect Osmo Action 3 to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.

DJI Osmo Action 3 Release Notes

Date:	2022.11.30
Firmware Version:	v01.02.10.10
DJI Mimo App iOS:	v1.8.6
DJI Mimo App Android:	v1.8.4

What's New

- Added HDR Video in shooting mode for wider dynamic range (10bit video and Enhanced Image Quality are enabled by default when recording HDR Video).
- Added shooting 10bit video in D-Cinelike mode, providing wider color grading for post-production (Only available for certain resolutions and frame rates).
- Added Enhanced Image Quality in video shooting mode, extending the dynamic range and displaying more highlight and shadow details (Only available for certain resolutions and frame rates).
- Added Timecode for synchronization. When using Timecode, Osmo Action 3 can be synchronized by the system settings or the time code synchronizer. This improves the post-production efficiency when shooting with multiple cameras.
- Added OTG (USB On-the-GO) connection. Android devices can connect to the camera to transfer files.
- Added RockSteady+ for better stabilization.
- Added support for 16:9 vertical display livestream.
- Added Narrow option for FOV.
- Added options for Auto Power Off. 1 min and 2 min are now available.
- Added support for Arabic in camera system settings.

Notes:

Custom Mode settings will be reset after the firmware update.

If the update fails, follow the steps for troubleshooting.

1. Restart Osmo Action 3 and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect Osmo Action 3 to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.

DJI Osmo Action 3 Release Notes

Date:	2022.10.14
Firmware Version:	v01.01.05.40
DJI Mimo App iOS:	v1.8.3
DJI Mimo App Android:	v1.8.2

What's New

- Enhanced the clarity of certain configurations.
- Added volume control function. High, medium, low, and mute are now available.
- Speeded up the boot time of the camera.
- Optimized detection algorithms of the touchscreens to reduce false touches when going in and out of water.
- Optimized automatic exposure to improve image quality and enhance color performance when used in scenes with low light.
- Added automatic screen orientation when playing back footage.
- Optimized the edge distortion of footage when Standard (Dewarp) is selected.
- Improved the compatibility with Android 13.
- Fixed some minor bugs.

Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart Osmo Action 3 and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect Osmo Action 3 to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.