



## DJI Osmo Pocket 4 Release Notes

---

Date:	2026.04.16
Firmware Version:	v01.01.32.02
DJI Mimo App iOS:	v2.8.1
DJI Mimo App Android:	v2.8.1
DJI Mic 3 Transmitter:	v02.00.10.01
DJI Mic Mini Transmitter:	v01.01.00.56
DJI Mic 2 Transmitter:	v04.05.02.31

---

### What's New

- Added support for burst shooting to SuperPhoto mode. Quickly press the shutter/record button for multiple times for bursting shooting, allowing to capture highlight moments easily. After shooting, wait until saving is complete.
- Added support for Live Photos in Standard Photo mode. When enabled, you can capture live photos in the camera and quickly export them to your mobile device using DJI Mimo.
- Added support for automatic Low-Light Image Enhancement in Video mode. When enabled, the camera will automatically detect low-light environment and switch to low-light mode, helping to improve image brightness and reduce noise. This feature is enabled by default and can be disabled in shooting settings.
- Improved zoom smoothness for more natural zooming effects when recording videos.
- Improved the image quality in Video mode for backlit scenes.
- Added a second page settings to the Control Center. Swipe down to open Control Center, then swipe left to view it.
- Optimized the interactive interface layout for improved user experience.
- Fixed some known issues.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart Osmo Pocket 4 and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect Osmo Pocket 4 to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.