



DJI Osmo Pocket 4 Release Notes

Date:	2026.04.16
Firmware Version:	v01.01.32.02
DJI Mimo App iOS:	v2.8.1
DJI Mimo App Android:	v2.8.1

What's New

- Added support for burst shooting to SuperPhoto mode. Quickly press the shutter/record button for multiple times for bursting shooting, allowing to capture highlight moments easily. After shooting, wait until saving is complete.
- Added support for Live Photos in Standard Photo mode. When enabled, you can capture live photos in the camera and quickly export them to your mobile device using DJI Mimo.
- Added support for automatic Low-Light Image Enhancement in Video mode. When enabled, the camera will automatically detect low-light environment and switch to low-light mode, helping to improve image brightness and reduce noise. This feature is enabled by default and can be disabled in shooting settings.
- Improved zoom smoothness for more natural zooming effects when recording videos.
- Improved the image quality in Video mode for backlit scenes.
- Added a second page settings to the Control Center. Swipe down to open Control Center, then swipe left to view it.
- Optimized the interactive interface layout for improved user experience.
- Fixed some known issues.

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4 and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4 to DJI Mimo and try the update again.Contact DJI Support if the update fails again.
2. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:
 - DJI Mic 3 Transmitter: v02.00.10.01 or above
 - DJI Mic Mini Transmitter: v01.01.00.56 or above
 - DJI Mic 2 Transmitter: v04.05.01.11 or above