



DJI Power 2000 Release Notes

Date:	2025.09.22
Firmware Version:	v 01.00.13.00

What's New

- Added support for Shelly 3EM-63W Gen3, Shelly 3EM-63T Gen3, and Shelly Pro 3EM 3CT 63.
- Optimized Grid-Tied ESS functions. *
- Fixed some known issue.

* Grid-Tied functions are only supported in some countries and regions. Visit the link for more details <https://www.dji.com/power-2000/faq>.

Notes:

If the update fails, follow the steps for troubleshooting.

1. Disconnect the computer and all connected devices from the power station.
2. Press and hold the power button for more than five seconds to power off the power station, and exit DJI Assistant 2 (Power Series).
3. Press and hold the AC button and the power button simultaneously. Connect the power station to the computer with a USB-C cable.
4. Retry updating the firmware to the latest version using DJI Assistant 2 (Power Series).



DJI Power 2000 Release Notes

Date:	2025.07.31
Firmware Version:	v 01.00.12.00

What's New

- Added support for Energy Saver mode. Users can enable Scheduled Periods or Grid-Tied ESS* in DJI Home App. The power station can be used for energy storage, helping to optimize the energy usage and save on electricity costs.

* Grid-Tied functions are only supported in some countries and regions. Visit the link for more details <https://www.dji.com/power-2000/faq>.

Notes:

If the update fails, follow the steps for troubleshooting.

1. Disconnect the computer and all connected devices from the power station.
2. Press and hold the power button for more than five seconds to power off the power station, and exit DJI Assistant 2 (Power Series).
3. Press and hold the AC button and the power button simultaneously. Connect the power station to the computer with a USB-C cable.
4. Retry updating the firmware to the latest version using DJI Assistant 2 (Power Series).

<https://www.dji.com/power-2000>



DJI Power 2000 Release Notes

Date:	2025.07.02
Firmware Version:	v 01.00.11.00

What's New

- Improved stability.
- Fixed some known issues.

Notes:

If the update fails, follow the steps for troubleshooting.

1. Disconnect the computer and all connected devices from the power station.
2. Press and hold the power button for more than five seconds to power off the power station, and exit DJI Assistant 2 (Power Series).
3. Press and hold the AC button and the power button simultaneously. Connect the power station to the computer with a USB-C cable.
4. Retry updating the firmware to the latest version using DJI Assistant 2 (Power Series).