



## Osmo Action Release Notes

---

Date:	2019.12.03
Firmware:	v01.07.00.20
DJI Mimo App iOS:	v1.2.9
DJI Mimo App Android:	v1.2.8

---

### What 's New?

- Added Loop Recording shooting mode.
- Optimized sound for external microphone.
- Fixed issue: there was live view latency when video resolution was set to 4K with 24/25/30 fps.

### Notes:

- If the update fails, restart Osmo Action and DJI Mimo, and retry. Alternatively, download the latest firmware from the official DJI website to a microSD card to update.



## Osmo Action Release Notes

---

Date:	2019.09.30
Firmware:	v01.06.00.20
DJI Mimo App iOS:	v1.2.4
DJI Mimo App Android:	v1.2.4

---

### What 's New?

- Added Hyperlapse.
- Added time settings for turning the touchscreen off automatically while recording.
- Added Thai and Arabic languages for Osmo Action.
- Fixed issue: there was live view latency when video resolution was set to 2.7K and 1080p with 24/25/30 fps.

### Notes:

- If the update fails, restart Osmo Action and DJI Mimo, and retry. Alternatively, download the latest firmware from the official DJI website to a microSD card to update.



## Osmo Action Release Notes

---

Date:	2019.08.06
Firmware:	v01.05.00.10
DJI Mimo App iOS:	v1.2.0
DJI Mimo App Android:	v1.2.0

---

### What 's New?

- Added ability to switch between front and rear screen in Slow Motion.
- Added ability to switch between front and rear screen in all modes without interrupting recording.
- Optimized EIS for 60 fps videos.
- Added Italian and Brazil Portuguese languages for Osmo Action.

### Notes:

- If the update fails, restart Osmo Action and DJI Mimo, and retry. Alternatively, download the latest firmware from the official DJI website to a SD card to update.



## Osmo Action Release Notes

---

Date:	2019.07.17
Firmware:	v01.04.00.10
DJI Mimo App iOS:	v1.1.8
DJI Mimo App Android:	v1.1.8

---

### What's New?

- Added Underwater AWB.
- Added ability to double tap to enlarge photos.
- Added full screen display in playback for photos and videos shot in portrait mode.
- Added function where the screen automatically turns off three seconds after finishing a SnapShot.
- Added shutter and exposure display in Auto mode.
- Added EV adjustment for Auto ISO in M mode.
- Added RockSteady icon to the front screen.
- Added Spanish and Russian languages for Osmo Action.
- Increased loading speed of photos and videos when using playback in DJI Mimo.
- Optimized video sharpness when using D-Cinelike.

### Notes:

- If the update fails, restart Osmo Action and DJI Mimo, and retry. Alternatively, download the latest firmware from the official DJI website to a SD card to update.



## Osmo Action Release Notes

---

Date:	2019.06.10
Firmware:	v01.03.00.10
DJI Mimo App iOS:	v1.1.4
DJI Mimo App Android:	v1.1.4

---

### What 's New?

- Optimized 8x slow motion video quality.
- Fixed issue: when recording for an extended period, the video and audio became out of sync.
- Fixed issue: when using playback, the camera occasionally restarted.
- Fixed issue: when recording, the camera could not connect to DJI Mimo.

### Notes:

- If the update fails, restart Osmo Action and DJI Mimo, and retry.



## Osmo Action Release Notes

---

Date:	2019.05.15
Firmware:	v01.02.00.10
DJI Mimo App iOS:	v1.1.0
DJI Mimo App Android:	v1.1.0

---

### What 's New?

- Updated the EIS to RockSteady.
- Added two second and five second timers to countdown in photo mode.
- Optimized system sounds.
- Increased Wi-Fi connection stability.
- Improved Timelapse and HDR video quality.

### Notes:

- If the update fails, restart Osmo Action and DJI Mimo, and retry.