



## DJI Osmo 360 Release Notes

---

Date:	2026.2.24
Firmware Version:	V01.03.08.70
DJI Mimo App iOS:	V2.7.2
DJI Mimo App Android:	V2.7.2

---

### What's New

- Added the Adaptive Tone feature. In Panoramic Video mode, tap the image/audio parameters icon on the right, then tap Adaptive Tone to enable this feature. Footage recorded with this feature enabled will be rendered with enhanced contrast and depth in the DJI Mimo app. (App version 2.7.2 or later is required. Support for this feature varies by shooting specifications. Refer to the actual interface)
- Improved color performance in snow scenes.
- Fixed some minor bugs.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart the camera and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect the camera to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.



## DJI Osmo 360 Release Notes

---

Date:	2026.1.15
Firmware Version:	V01.03.08.70
DJI Mimo App iOS:	V2.6.8
DJI Mimo App Android:	V2.6.8

---

### What's New

- Added support for 9:16 aspect ratio when recording in **Single Lens > Boost Video** mode, including 2.7K/4K recording at 25/30/50/60/100/120 fps. This simplifies the production of vertical video content.
- Added support for livestreaming when using Single Lens mode. Download the latest version of the DJI Mimo app and connect your camera. Enter the camera view, swipe to LIVESTREAM at the bottom, and complete the setup to start livestreaming. During a livestream, you can switch between the front and rear lenses and record the stream on the camera.
- Added the Film Tone feature, providing six film tone filters. Tap the image/audio parameters icon on the right, tap Film Tone, and then select a filter. (Support for this feature varies by shooting mode; Refer to the actual interface)
- Added the Anti-Flicker mode to the stabilization scenario options. This mode helps reduce image flicker. To enable this mode, tap the image/audio parameters icon on the right, tap Stabilization Scenario, and then scroll to Anti-Flicker.
- Enhanced panoramic photo quality, including image tone and detail.
- Fixed some minor bugs.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart the camera and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect the camera to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.



## DJI Osmo 360 Release Notes

---

Date:	2025.09.30
Firmware Version:	V01.02.07.21
DJI Mimo App iOS:	V2.4.16
DJI Mimo App Android:	V2.4.16

---

### What's New

- Fixed some minor bugs.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart the camera and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect the camera to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.



## DJI Osmo 360 Release Notes

---

Date:	2025.09.15
Firmware Version:	V01.02.07.20
DJI Mimo App iOS:	V2.4.8
DJI Mimo App Android:	V2.4.8

---

### What's New

- Added SuperNight mode in Single Lens mode, supporting 2.7K 16:9, 2.7K 4:3, 4K 16:9, and 4K 4:3 recording at 25/30 fps with an ultra-wide field of view and enhancing video quality in night scenes.
- Added support for DJI Mic 3. Press and hold the linking button on a DJI Mic 3 transmitter for 2 seconds. Then, enter the liveview on the camera and swipe down from the top of the screen, tap the Wireless Microphone icon, and tap TX1/TX2 to connect. The camera can connect up to two transmitters simultaneously.
- Added the album password feature to enhance privacy protection. Enter the liveview and swipe down from the top of the screen. Then, tap the Settings icon and tap Password. Once the password takes effect, verification is required when accessing playback for the first time after powering on.
- Fixed some minor bugs.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart the camera and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect the camera to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.



## DJI Osmo 360 Release Notes

---

Date:	2025.09.01
Firmware Version:	V01.01.06.41
DJI Mimo App iOS:	V2.4.0
DJI Mimo App Android:	V2.4.0

---

### What's New

- Added the Twist Shot feature. When the camera is powered on, you can twist the selfie stick twice to take a photo or start recording. To enable this feature, enter the liveview and swipe down from the top of the screen. Then, swipe left and tap the Twist Shot icon.
- Enhanced panoramic video quality for 8K recording at 48/50fps.
- Enhanced color reproduction and detail in D-Log M mode.
- Fixed some minor bugs.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart the camera and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect the camera to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.



## DJI Osmo 360 Release Notes

---

Date:	2025.08.19
Firmware Version:	V01.01.06.30
DJI Mimo App iOS:	V2.3.4
DJI Mimo App Android:	V2.3.4

---

### What's New

- Enhanced panoramic video quality by optimizing Auto Exposure (AE) strategies and color rendering.
- Enhanced SuperNight video quality by optimizing noise reduction and color rendering.
- Fixed some minor bugs.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart the camera and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect the camera to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.



## DJI Osmo 360 Release Notes

---

Date:	2025.07.31
Firmware Version:	V01.01.06.20
DJI Mimo App iOS:	V2.3.0
DJI Mimo App Android:	V2.3.0

---

### What's New

- Supported 8K recording at 48/50fps in 360° mode.
- Added SuperNight mode in 360° mode, supporting 8K/6K recording at 24/25/30fps and enhancing color performance in night scenes.
- Added bitrate settings. You can switch between high bitrate and standard bitrate in system settings.
- Added support for 5K recording at 50/60 fps in 4:3 aspect ratio when using **Single Lens > Video** mode.
- Added Endurance Mode to significantly extend battery life. To enable this mode, switch to Panoramic Video mode, tap the parameter adjustment icon on the right, and then tap **Endurance Mode**.
- Added support for Osmo Action GPS Bluetooth Remote Controller.
- Fixed some minor bugs.

### Notes:

If the update fails, follow the steps for troubleshooting.

1. Restart the camera and DJI Mimo.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect the camera to DJI Mimo and try the update again.

Contact DJI Support if the update fails again.