

 OSMO Series Accessory Compatibility List

Accessory	Osmo Nano	Osmo 360	Osmo Action 5 Pro	Osmo Action 4	Osmo Action 3	DJI Action 2	Osmo Action
Osmo Action Multifunctional Charging Handle	×	×	√	√	×	×	×
Osmo Action FOV Boost Lens	×	×	√	√	×	×	×
Osmo Action Cold Shoe Expansion Kit	×	×	√	√	√	×	×
Osmo Helmet Chin Mount Clip	√ ¹	√ ⁴	√	√	√	√	√
Osmo Flexible Mount	√ ¹	×	√	√	√	√	√
Osmo Action Extreme Battery Plus (1950 mAh)	×	√	√	√	√	×	×
Osmo Action 5 Pro Glass Lens Cover	×	×	√	×	×	×	×
Osmo Action Mini Extension Rod	×	×	√	√	√	×	×
Osmo Action 1.5m Extension Rod Kit	×	×	√	√	√	√	√
Osmo Action 360° Wrist Strap	×	√	√	√	√	×	×
Osmo Action Curved Adhesive Base	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Curved Adhesive Base Kit	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Adhesive Base Kit	×	√ ⁴	√	√	√	×	×
Osmo Action Quick-Release Adapter Mount	×	√ ⁴	√	√	√	×	×
Osmo Action Mounting Kit	×	×	√	√	√	√	√
Osmo Magnetic Ball-Joint Adapter Mount	×	√	√	√	√	√	×
Osmo Locking Screw	√	√	√	√	√	√	√
Osmo Backpack Strap Mount	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Hanging Neck Mount	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Mini Handlebar Mount	×	√	√	√	√	×	×
Osmo Action Handlebar Mount	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Suction Cup Mount	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Chest Strap Mount	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Helmet Chin Mount	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Biking Accessory Kit	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Road Cycling Accessory Kit	×	√	√	√	√	×	×
Osmo Action Bike Seat Rail Mount	√ ¹	√ ⁴	√	√	√	√	√
Osmo Action Surfing Tethers	×	√	√	√	√	√	√
Osmo Action Surfing Tether Kit	×	√ ⁴	√	√	√	×	×
Osmo Action 60m Waterproof Case	×	×	√	√	√	×	×
Osmo Action Diving Accessory Kit	×	×	√	√	√	×	×
DJI Floating Handle	√ ¹	×	√	√	√	√	√
Osmo Action ND Filters Set	×	×	√	√	√	×	×
Osmo Action 4 Glass Lens Cover	×	×	×	√	×	×	×
Osmo Action Horizontal-Vertical Protective Frame	×	×	√	√	√	×	×
Osmo Action GPS Bluetooth Remote Controller	×	√	√	√	×	×	×
Osmo Action 3.5mm Audio Adapter	×	×	√	√	√	×	×
Osmo Action Extreme Battery	×	√	√	√	√	×	×
Osmo Action Multifunctional Battery Case	×	×	×	√	√	×	×
Osmo Action Multifunctional Battery Case 2	×	√	√	√	√	×	×
Type-C to Type-C PD Cable	√	×	√	√	√	√	√
DJI 30W USB-C Charger	√	√	√	√	√	√	√
DJI Action 2 Magnetic Protective Case	×	×	×	×	×	√	×
DJI Action 2 Remote Control Extension Rod	×	×	×	×	×	√	×
DJI Action 2 Waterproof Case	×	×	×	×	×	√	×
DJI Action 2 Macro Lens	×	×	×	×	×	√	×
DJI Action 2 Magnetic Clip	×	×	×	×	×	√	×
DJI Action 2 Magnetic Ball-Joint Adapter Mount	×	×	√	√	√	√	×
Osmo Action Bite Mount	√ ¹	√ ⁴	√	√	√	√	√
Osmo 360 Battery Extension Rod	×	√	×	×	×	×	×
Osmo Motorcycle Heavy-Duty Mount	√ ³	√	×	×	×	×	×
Osmo Adjustable Quick-Release Adapter Mount	×	√	×	×	×	×	×
Osmo 360 Transparent Lens Protectors	×	√	×	×	×	×	×
Osmo Hanging Neck Mount Max	√ ¹	√ ⁴	√	√	√	√	√
Osmo Third-Person Helmet Mount Kit	×	√	×	×	×	×	×
Osmo 70cm Invisible Selfie Stick	√ ³	√	×	×	×	×	×
Osmo 1m High-Strength Carbon Fiber Invisible Selfie Stick	√ ³	√	×	×	×	×	×
Osmo 1.2m Invisible Selfie Stick Kit	√ ³	√	×	×	×	×	×
Osmo 1.6m Tripod Selfie Stick	√ ³	√	×	×	×	×	×
Osmo 2.5m Extended Carbon Fiber Selfie Stick	√ ³	√	×	×	×	×	×
Osmo Dual Heavy-Duty Clamp	√	√	√	√	√	√	√
Osmo Vortex Rotating Handle	×	√	×	×	×	×	×
Osmo Bike Rear Mount Kit	×	√	×	×	×	×	×

1. Osmo Dual-Direction Quick-Release Adapter Mount (sold separately) is required.
2. Can be installed. Due to mismatched magnetic poles, use both hands to align the parts during installation and removal to prevent the device from falling.
3. Needs be used with the Osmo Nano Dual-Direction Magnetic Ball-Joint Adapter Mount.
4. Osmo Action Quick-Release Adapter Mount (sold separately) is required.