



PHANTOM 4 ADVANCED+

In the Box


Check that all of the following items are in your package. If any item is missing, please contact DJI or your local dealer.

Essentials


Aircraft Body x1



Remote Controller x1



Propeller Pairs x4




Intelligent Flight Battery x1



Battery count varies with different bundles.

Battery Charger x1



Power Cable x1



Manuals



- *In the Box*
- *Disclaimer and Safety Guidelines*
- *Intelligent Flight Battery Safety Guidelines*
- *Quick Start Guide*

Accessories*

Gimbal Clamp x1



USB OTG Cable x1



Micro USB Cable x1



Micro SD Card x1
(16GB)



Carrying Case x1



* Accessories are not covered by warranty.