

DJI MATRICE 100




In the Box

Standard Package

Check that all of the following items are in your package. If any item is missing, please contact DJI or your local dealer.


Center Frame × 1
(with Flight Controller, ESCs
and Battery Compartment)



Frame Arm × 4



Quick Release
Propeller Pair × 3



Remote Controller × 1




Mobile Device
Holder × 1



Intelligent Flight Battery
× 1 (TB47D)



Battery Charger × 1



Power Cable × 1



Micro USB Cable × 1



GPS Module × 1




GPS Bracket Set × 1




Arm Fastener × 4



Expansion Bay × 2



Gimbal Mounting
Plate × 1



Damper × 4



XT30-XT60 Cable × 1



UART Cable x 1



2.0 Hex Key x 1



Slotted Screwdriver x1



Double-Sided Tape



Screws



M2.5x5, M2.5x8,
M3x8 (self-tapping),
M3x5, M3x5.5

Manuals



DJI Matrice 100 In the Box

DJI Matrice 100 Disclaimer and Safety Guidelines

DJI Matrice 100 Intelligent Flight Battery Safety Guidelines

Optional Items


Zenmuse X3



Gimbal and Camera



ND Filter



Gimbal Lock



Gimbal Cables and Screws


Intelligent Flight Battery
(TB47D/TB48D)



Battery Compartment



Expansion Bay




Guidance Bracket Set




More optional items at <http://store.dji.com>



Exploded View



Assembled View



DJI Support:
<http://www.dji.com/support>

For more product information, visit the DJI Matrice 100 product page and download the *DJI Matrice 100 User Manual*.

<http://www.dji.com/product/matrice100>



If you have any questions about this document, please contact DJI by sending a message to **DocSupport@dji.com**.