


OSMO Base

Quick Start Guide

V1.0 2016.02



Disclaimer and Warning

Congratulations on purchasing your new DJI product. The information in this document affects your safety and your legal rights and responsibilities. Read this entire document carefully to ensure proper configuration before use. Failure to read and follow instructions and warnings in this document may result in serious injury to yourself or others, damage to your DJI product, or damage to other objects in the vicinity. This document and all other collateral documents are subject to change at the sole discretion of DJI. For up-to-date product information, visit <http://www.dji.com> and click on the product page for this product.

By using this product, you hereby signify that you have read this disclaimer and warning carefully and that you understand and agree to abide by the terms and conditions herein. You agree that you are solely responsible for your own conduct while using this product, and for any consequences thereof. You agree to use this product only for purposes that are proper and in accordance with all applicable laws, rules, and regulations, and all terms, precautions, practices, policies and guidelines DJI has made and may make available.

DJI accepts no liability for damage, injury or any legal responsibility incurred directly or indirectly from the use of this product. The user shall observe safe and lawful practices including, but not limited to, those set forth in this document.

Introduction

The Osmo Base provides a stable platform for your Osmo to stand upright.


Specifications

Dimensions: 126 mm x 90 mm x 44 mm

Weight: 162 g

Usage

To mount, place the Osmo inside the slot with the lanyard hole facing the release button. Ensure it is secure.




To remove the Osmo, hold down the release button.



- Be careful when mounting multiple accessories on the Osmo as this could cause the Osmo Base to topple over.
 - Removing without holding down the release button may damage the Osmo.
-

The Osmo Base provides a 1/4" thread underneath for mounting on a tripod.



- Do not over tighten the 1/4" thread to avoid damaging the Osmo Base.
-

The content in this document is subject to change.

Download the latest version from
www.dji.com/product/osmo

If you have any questions about this document, please contact DJI by sending a message to DocSupport@dji.com.

© 2016 DJI. All Rights Reserved.